







Assembly Instruction




Richmond TV Unit






Richmond TV Stand
parts list










contents of the bag

1		∅8 x 38mm	18PCS
2		∅8 x 30mm	12PCS
3		83 x 22mm	1PC


4		∅16 x 1.5mm	18PCS
5		∅13 x 1.2mm	18PCS
6		60 x 25mm	1PC







step 1



1		9PCS
2		6PCS
3		1PC
4		9PCS
5		9PCS
6		1PC

step 2



1		9PCS
2		6PCS
3		1PC
4		9PCS
5		9PCS
6		1PC