

MODEL: 60313

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THIS GEL BURNER SHOULD TAKE APPROXIMATELY 2 MINUTES TO ASSEMBLE.

UNPACK THE BURNER

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS: GEL BURNER BODY, CUP AND COVER.


PRODUCT USES ALCOHOL BASED FUEL GEL, SOLD SEPARATELY.

IMPORTANT NOTE: KEEP GEL BURNER AND FUEL GEL OUT OF REACH OF CHILDREN AND PETS, THIS PRODUCT IS NOT INTENDED FOR USE BY CHILDREN.


READ ALL INSTRUCTIONS AND WARNING PRIOR TO USE.

GEL BURNER ASSEMBLY


1. PLACE THE GEL BURNER BODY ON A LEVEL, STABLE SURFACE, THEN PLACE CUP INTO HOLE IN GEL BURNER BODY.



2. POUR CLEAR FUEL GEL SLOWLY AND CAREFULLY INTO CUPS NO HIGHER THAN 1" FROM THE TOP.



3. CAREFULLY LIGHT FUEL GEL WITH A LONG MATCH OR BBQ LIGHTER.



IMPORTANT NOTE:

1. ALWAYS USE THE BURNER ON A LEVEL, STABLE SURFACE.
2. KEEP FUEL GEL BOTTLE AWAY FROM FIRE OR FLAME.
3. POUR CLEAR FUEL GEL SLOWLY AND CAREFULLY INTO CUPS NO HIGHER THAN 1" FROM THE TOP.
4. NEVER ADD FUEL GEL TO AN OPEN FIRE OR FLAME AS THERE IS A DANGER OF A FLASH FIRE AND SEVERE BURNS.
5. ALWAYS PUT OUT THE FLAME WITH COVER AND LET THE CUPS COOL COMPLETELY BEFORE ADDING ADDITIONAL FUEL GEL.
6. FUEL GEL CONTAINS ISOPROPYL ALCOHOL, DO NOT DRINK OR SWALLOW OR GET IN EYES OR ON CLOTHES OR SKIN. IF ACCIDENTALLY SWALLOWED, DO NOT INDUCE VOMITING, CALL POISON CONTROL CENTER IMMEDIATELY.
7. DO NOT BLOW OUT FLAME, USE COVER TO EXTINGUISH FLAME, BE SURE FLAME IS COMPLETELY EXTINGUISHED.
8. DO NOT LEAVE BURNING GEL BURNER UNATTENDED.