



AVAILABLE PARTS ARE:
 70214GSPW (GLASS SHADE)
 08714BULB (BULB)

INSTALLATION INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

CAUTION: TO AVOID POSSIBLE ELECTRIC SHOCK, MAKE SURE THE ELECTRICITY IS SHUT OFF AT THE MAIN PANEL. IF YOU ARE REPLACING AN EXISTING FIXTURE, FIRST TURN THE FIXTURE OFF. NEXT, TURN THE WALL SWITCH OFF. FINALLY, GO TO THE MAIN FUSE OR BREAKER BOX IN YOUR HOME. TURN THE FUSE OR BREAKER TO THE OFF POSITION. SOME TYPES OF FUSES MUST BE UNSCREWED TO SHUT OFF THE POWER.

* ALL WIRING MUST BE DONE IN ACCORDANCE WITH NATIONAL AND LOCAL ELECTRIC CODES.

** IF YOU DO NOT HAVE ELECTRICAL WIRING EXPERIENCE, HAVE YOUR LANTERN INSTALLED BY A QUALIFIED LICENSED ELECTRICIAN.

*** THIS LANTERN IS TO BE MOUNTED TO A UL LISTED POST CAPABLE OF SUPPORTING THE WEIGHT OF THE LANTERN.

TOOLS: YOU WILL NEED THE FOLLOWING TOOLS OR EQUIPMENT: SCREWDRIVER, PLIERS, ADJUSTABLE WRENCH.

UNPACK THE LANTERN: YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE PACKAGE: FINIAL, RUBBER WASHER, ROOF, HARP, BULB, SOCKET RING, METAL RING, LANTERN BODY, (3) MOUNTING SCREWS AND (3) WIRE CONNECTORS. TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

INSTALLING THE LANTERN

1. PLACE GLASS SHADE, HARP OVER SOCKET, THEN SECURE WITH METAL RING AND SOCKET RING.
2. INSTALL A 18 WATT MAXIMUM TYPE "G24Q-2" BULB (INCLUDED) INTO SOCKET.
3. PLACE ROOF ONTO HARP, THEN SECURE WITH RUBBER WASHER AND FINIAL.
4. RAISE THE LANTERN UP TO POST FOR WIRING. ATTACH THE WHITE OR RIBBED LANTERN WIRE TO THE WHITE SUPPLY WIRE USING A WIRE CONNECTOR. ATTACH THE BLACK OR SMOOTH LANTERN WIRE TO THE BLACK SUPPLY WIRE WITH A WIRE CONNECTOR. ATTACH THE LANTERN AND SUPPLY GROUND WIRES TOGETHER AND SECURE WITH A WIRE CONNECTOR.
5. PLACE LANTERN ON POST AND ALIGN HOLES, THEN SECURE WITH (3) MOUNTING SCREWS.
6. RESTORE POWER, THE LANTERN WILL TURN ON AUTOMATICALLY EVERY NIGHT.

